

INFORMATIVE NOTE Read carefully before use

Art. GP17058	Neoprene pot holder						
CHARCTERISTICS:	These pot holder are a Category 2 Personal Protective Equipment (PPE). They have the CE marking as they comply with the requirements of Regulation (EU) 2016/425 and have been certified by the Notified Organization RICOTEST (No. 0498 - Via Tione 9 - 37010 Pastrengo - VR). The compliance with the requirements of the Regulation has been verified through the technical standards EN 420:2003+A1:2009, EN 388:2016+A1:2018 and EN 407:2004.						
PERFORMANCE:		Testina	I I avail althoise al	I I avala sasisad		 1	
		Testings	Level obtained	Levels reqired MIN -	MAX		
	EN 388	Abrasion Cut	2 X	1	5]	
		Tear	1	1	4		
		Perforation	X	1	4		
	Resistance to cutting objects EN ISO 139		X	A	F		
	X = characteristic not ascertained or not applicable.						
	According to EN 407 : protective gloves against thermal risks (heat contact only) Contact heat 2 (max 27 s a 250°C) Min. 1 – max 4						
	Contact neat		2 (IIIax 21 S a 250 C)	IVIIII. I – IIIAX 4			
RECOMMENDED USES::	These pot holders are suitable for protecting hands from contact with pots, hot plates, ovens (within the limits of the marked protective levels).						
RISKS:	Suitable for risks of:						
	contact heat.						
	Not suitable for risks of abrasion, cut, perforation, heat and fire (except contact heat), chemical products, cold and for all uses not mentioned in this Informative Note and in particular those that fall under						
	Category 3 of Personal Protective Equipment.						
	Do not place in direct contact with heat sources (flames, electric plates, etc.)						
WARNING::	The presence of allergenic substances is not known to the manufacturer. Please report any observed						
	cases of hypersensitivity or allergic reaction						
PRELIMINARY CHECKS AND	Before use, make a visual check of the palm mitten to make sure it is in perfect condition, clean and						
USE: WARNINGS	intact. If it is not intact (visible damage such as unstitching, breakages or soiling) it must be replaced.						
INSTRUCTIONS FOR	The pot holder must be stored in its original packaging, in a dry place away from heat sources. Avoid						
MAINTENANCE AND EXPIRY	contact with solvent products that can cause alteration of the characteristics.						
DATE:	In particularly severe conditions of use or in environments with special situations, it is possible that the						
	palm mitten undergoes sudden degradation not foreseen by the manufacturer and therefore it is not						
	possible to establish an "expiry date", even if, in relation to the natural deterioration of the material with						
	which this PPE is produced and the consequent reduction in quality, it is considered appropriate to						
	recommend its use no later than 5 years from purchase. Conditions other than those recommended could shorten the life of the product.						
CLEANING:	Washable with water and mild detergent at 30 ° C (tested 3 washing cycles).						
MARKING:	On the label sewn on the pot holder:						
		CE marking, which certifies the compliance of the PPE with the essential health and safety requirements of the Regulation.					
	GHIDINI	Registered t	rademark of the manu	facturer.			
	GP17058	Model					
	[]i	Pictogram th	Pictogram that refers to the Informative Note				

The EU declaration of conformity is available on the website www.ghidinicipriano.it

